


Remarks:

1. All dimensions in mm.
2. Side view of foundations is from inside of property.
3. Prepare view of foundation with concret class C25. Concter must be reinforced with fibres and flat on top.
4. For gate installation use anchors M16x240 or longer. Anchors must be over concrete surface 80mm minimum
5. Use this drawing as suggestion. Exact foundation dimensions have to be verified concerning local soil parameteres and freeze depth.

|   |              |  |                    |                         |
|---|--------------|--|--------------------|-------------------------|
|  |              | Halsäng Stängsel AB<br>Halsäng 4<br>521 93 Falköping<br>SWEDEN<br>www.halsang.se |                    |                         |
|   |              | Material   | Coating            | Width                   |
| Main post   |              | Frame  | Reinforcement      | Infill                  |
| Designed by<br>I. Stęchty   |              | Edited by  | Date<br>2018-07-10 | Order number            |
| Scale<br>1 : 24   | Format<br>A3 | Drawing<br>ODEN FP 8000 Right  |                    | Number<br>SLG.O.F.8.2.R |