

1. All dimensions in mm.

2. Prepare foundation with concrete class C25. Concrete must be reinforced with reinforcement bars or fibres and flat on the top.

3. For turnstile installation, put turnstile on prepared foundation- wire pipes with 230V AC supply should be just under turnstile's main posts. lay out and drill holes for appropriate anchors.

4. Placing turnstile on foundation depending on detailed turnstile size- to be chosen on installation site.

5. This is suggest foundation plan. Dimensions, reinforcement, anchoring.

HALSANG	Rema
Designed by	Scale
D.Surma	
Edited by	Heigh
Number	Draw
S.004690	

		_ -		
		1		
S				
	Format	Data	Sheet numer	
	A3	26.06.2023	1/1	
s s 20				